

194 Series



Dimensioni d'ingombro

L'illustrazione raffigura le dimensioni di massima della pompa e i punti di fissaggio.

Overall dimensions

The illustration shows the approximate dimensions of the pump and the mounting points.

Dimensions hors-tout


L'illustration représente les dimensions hors-tout de la pompe et les points de fixation.

Außenmaße


Die Abbildung zeigt die Außenmaße der Pumpe und die Befestigungspunkte.

Dimensiones

La ilustración presenta las dimensiones generales de la bomba y los puntos de fijación.



OPTIONAL



1948520